



Motorcycle • Snowmobile • Boat • ATV • Personal Watercraft



Value/Deluxe Series Tank Bag System With Map Pocket Installation Instructions

Congratulations on your purchase of a Fastrax Tank Bag System. Assembled to your motorcycle, the system will provide extra storage for cell phones, maps, clothes and other items for short or long trips. Please carefully read the information below before installation.

WARNING

The Universal Harness must be installed so as not to interfere with full left or right steering. Failure to ensure that adequate steering is available will result in serious injury.

Universal Harness Installation

1. Remove seat
2. Locate front of harness with two large quick-release buckles.
3. Disengage buckles and position harness loosely on gas tank between steering head and front of tank.
4. Thread front strap around steering post and clip to harness buckles.
5. The rear of the harness contains one web strap with slide lock and quick release buckle. Slide web strap under tank mounting or around frame.
6. Weave end of web strap through tri-glide (slide adjustment). Buckle to harness.
7. Adjust front and rear of harness using the combination of slider locks and the quick-release buckles to securely fasten the harness on the gas tank.
8. Check to make sure harness is centered on tank.
9. Reassemble seat with care. Slide locks should not interfere with attachment. If you encounter interference, adjust slider locks.

Magnetic Mount Harness Installation

Place and center magnetic unit directly on METAL tank. Position to conform to tank profile and not to interfere with full left or right steering.

NOTE: Do not put anything with credit cards near the magnets!

WARNING

Overloading any tank bag will result in a high center of gravity, which will cause bike to become top heavy and susceptible to unexpected tipping, especially on lean-in while negotiating high speed turns. **MAXIMUM ALLOWABLE LOAD LIMIT IS 5 LBS.**

Care & Cleaning:

This product is supplied with a gasoline and scratch resistant neoprene layer. However, care should be taken to avoid gas spills and a heavy buildup of dust and/or dirt under the harness. Excessive dust and/or dirt may become embedded in the neoprene, which may lead to scratches in the painted finish. Wiping with a mild bike wash detergent and applying a good quality wax will reduce the chance of scratching. Remove the bags before washing the bike. Use a mild detergent and soft brush to remove dirt or road grime from the bags. Rinse thoroughly and allow to air dry before using. Do not put in washer or dryer. Dry-cleaning is not recommended.

Note: Your bags are manufactured from heavy-weight water-proof polyester materials. However, in the event of heavy rain, moisture may enter the bags through seams or zippers. It is highly recommended that important papers, valuable items, or clothing be wrapped in plastic for added protection