

Please Read! Please read and understand these instructions completely before installation to avoid possible injury to yourself, or damage to the accessory or vehicle. Read all **Cautions, Warnings** and **Notes** within installation instructions and on bags. If you are unsure about securing the bladder, please contact us at 1-800-558-7755 ext. 123.

Monday through Friday 8:00 am - 4:30 pm CST

⚠ WARNING

- * Keep out of the reach of infants and small children.
- * Hydration Bladder is to be used **ONLY** when bike is parked!

1. PARTS LIST:

This Product contains the following components. Before beginning installation confirm there are no missing or damaged components.

Item #	Description	Qty
1.	Hydration Bladder	1

2. PREPARATION:

- a. Before using your Guardian Hydration bladder for the first time, rinse out the inner bladder using clean water. This will help remove any plastic taste from the material.
- b. We recommend filling the bladder only with water as other liquids may leave lingering tastes and odors.
- c. To fill the bladder, unscrew the large fill cap at the top and fill with water.
- d. When the bladder is full, secure the cap tightly to prevent liquid from escaping.



3. INSTALLATION:

- a. Bladder can be used with many different bags. We recommend using it with the Tank Bag of the Fastrax Elite Sport Bike Luggage.
- b. To install the bladder into the Tank Bag you must open the lid of the Tank Bag.
- c. Once open you will find a compartment located in the lid. Unzip to open. (Fig 1)
- d. Unscrew the tube from the Hydration Bladder. (Fig. 2)



- e. Thread the tubing through the large access port located at the top of the lid. (Figs. 3 & 4)
- f. Reconnect the tube and mouthpiece to the bladder.
- g. Place the bladder into the lid and zip the lid compartment closed. (Fig. 5)



⚠ CAUTION
Check for leaks before every use.

4. CARE AND CLEANING: (Remove from motorcycle)

- a. To clean the inner bladder, simply fill with fresh warm water, shake vigorously, and drain.
- b. To eliminate odors from the inner bladder, fill with fresh water and add a tablespoon of baking soda. Let sit overnight and then drain and rinse with warm water.
- c. To sanitize the inner bladder, fill with warm water and add two teaspoons of bleach. Let sit overnight and then drain and rinse thoroughly with warm water.
- d. When not using the hydration system, remove the inner bladder and drain all remaining liquid. Leave large fill cap open and hang the bladder upside-down if possible to allow moisture to evaporate out.

5. CUSTOMER SERVICE:

For further information contact Dowco inc. at
DOWCO Inc.
4230 Clipper Dr.
Manitowoc, WI 54220 USA
Phone: 1-800-558-7755
Fax: 920-682-5891
email: feedback@dowco-inc.com